Using MCKAL MP866, MP867, MP867-IR or MP901

for SmartCard and Singapore NETS cashcard

IMPORTANT NOTE:

- *i.* NETS cashcard is a NETS proprietary implementation. Hence, to read the cashcard transaction log, you can either use (a) NETS online website or (b) NETS E-Wallet application.
- *ii.* For support of NETS online website or NETS E-Wallet application, please contact NETS Singapore.
- iii. MEKAL is not the owner of NETS cashcard, its online website or NETS E-Wallet and is not obliged to provide technical support for NETS cashcard, its online website or NETS E-Wallet.

This guide will guide you through the additional setup of the necessary drivers on your Windows system for using SmartCard and Singapore NETS cashcard.

A What you need

- 1. MCKAL MP866, MP867, MP867 with IR or MP901
- 2. 1 valid working NETS cashcard

B Setting up your PC/Laptop with the drivers

- Drivers (MP866/MP867/MP867-IR/MP901) must have been installed on your Windows system. If not, please proceed to download the relevant User Guides and drivers from <u>http://www.mckal.com/support.php</u>.
- 2. Complete the installation as instructed before proceeding with Part C.

C Reading your CashCard



Note the direction of the cashcard - chip should face up

Option 1 – Using the Cashcard offline (with NETS E-Wallet)

- 1. Download NETS E-Wallet from http://www.mckal.com/download/NETSE-Wallet230Full.zip
- 2. Run NETSE-Wallet230Full.zip to install NETS E-Wallet.
- 3. Download http://www.mckal.com/download/McKALCashcardReaderUpdate.zip
- 4. Unzip McKALCashcardReaderUpdate.zip
- 5. Run McKALCashcardReaderUpdate.exe
- 6. Launch "NETS E-Wallet" and click login (as guest and no password needed).
- 7. Go to "Transaction History" tab \rightarrow "CashCard Detail" for your transaction log.

Option 2 – Using the Cashcard functions online with NETS website

- 1. Go to <u>www.nets.com.sg</u>
- 2. Select "NETS CASHCARD"
- 3. Select "NETS CashCard Online Services" to access your cashcard transactions.
- 4. IMPORTANT: You must allow and install the Java API when prompted.
- 5. Alternatively, you can go direct to http://www.nets.com.sg/consumers/netscashcard/ncc_services.php

Troubleshooting MCKAL MP866, MP867, MP867-IR or MP901

for SmartCard and Singapore NETS cashcard on NETS Online Website

General

- **Problem Description**
- 1. Cannot detect cashcard

Possible Cause

1. Cashcard is inserted incorrectly.

Resolution



Note the direction of the cashcard - chip should face up

General

Problem Description

- 1. Required files cannot be found or
- 2. Restrictions to download and auto-install SmartCardAPI.jar

Possible Cause

- 1. The following files are not in the respective directories.
 - a) C:\Windows\system32\scard.dll
 - b) C:\Windows\system32\scdll32.dll
 - c) C:\Program Files\Java\jre6\lib\ext\SmartCardAPI.jar

Resolution

- 1. Download http://www.mckal.com/download/NETSOnlineDLLAPI.zip.
- 2. Unzip and copy the 3 files to their respective directories.

On Windows XP

Problem Description

1. Error messages when viewing cashcard transactions or checking cashcard balance.

Possible Cause

1. Insufficient adminstrator rights.

Resolution

- 1. Assign Administrator rights to your user account.
- 2. Set your User Account Control (UAC) to **never notify**.
 - a) Go to "Control Panel"
 - b) Click on "All Control Panel items"
 - c) Click on "Action Center"
 - d) On the top left, click on "User Account Control settings"
 - e) Set to "never notify"

On Windows Vista

Problem Description

1. Cannot download of "SmartCardAPI.jar" by Java to "java\lib\ext" directory.

Possible Cause

1. New feature on Windows Vista - "User Account Control" turned on by default that prevents the download from completing.

Resolution

- 1. Assign Administrator rights to your user account.
- 2. Follow these steps to turn off "User Account Control" on Vista
 - a) Click "Window" > "Control Panel" > "User Accounts"
 - b) If there are multiple accounts, please click on the correct account that you will be using
 - c) Click "Turn User Account Control on or off"
 - d) Uncheck "Use User Account Control (UAC) to help protect your computer" >Click "OK"
 - e) When prompted to restart, click "Restart Now"
 - f) UAC will be disabled after restart.
- 3. After restart, you may try to read your cashcard via NETS online website again.

Disclaimer

MCKAL is not responsible for the support of all NETS Cashcard software or online website and will not be obligated to support them. For Java support, please check with your system technical support.

For NETS online website and NETS E-Wallet, please contact NETS Singapore.

[©] MMXI MCKAL, All Rights Reserved. The NETS trademark and logo ("NETS Trademarks") are registered trademarks owned by NETS Singapore.