

55

NEXUS
world connector


by **MCKAL**

www.mckal.com


INSTRUCTIONS

©2007 MCKAL. All rights reserved. All warranty information, product features and specifications are correct at the time of printing and may subject to change without notice.


PIN SELECTION



Push slide-switch to the desired country pin type.




Depress slide-switch and slide down fully as shown to reveal pins. Release the slide-switch to lock the pins in place.




To retract the pins after use, depress the slide-switch and slide upward fully as shown. Release the slide-switch to lock.

FUSE REPLACEMENT


Caution! Ensure the plug is disconnected to any electrical source before attempting to change fuse!




Push slide-switch fully to the right to release the power input unit.



Detach power input unit to reveal fuse socket, shown in figure 3.



To replace the fuse, use a screw-driver to release the cap. Use only the correct type of fuse. (Fuse specifications on last page)



To re-assemble, place fuse cap back and screw to close. Then re-attach the power input unit. Push slide-switch left.

FACE FRONT

45

45

45

45

45

45

45


315

COUNTRY PIN

EUROPE




UNITED KINGDOM



AUSTRALIA



USA



EUROPE

Albania, Algeria, Angola, Argentina, Austria, Azores, Balearic Islands, Bangladesh, Belgium, Bolivia, Bosnia, Brazil, Bulgaria, Burkina Faso, Burundi, Cameroon, Canary Islands, Cape Verde, Central African Republic, Channel Islands, Chile, Comoros, Congo, Croatia, Czech Republic, Dem. Rep. of Congo (Zaire), Cote d'Ivoire (Ivory Coast), Cyprus, Denmark, Djibouti, Egypt, El Salvador, Equatorial Guinea, Eritrea, Faeroe Islands, Finland, French Guiana, Gabon, Germany, Gibraltar, Greece, Greenland, Guadeloupe, Guinea, Guinea-Bissau, Hungary, Iceland, India, Indonesia, Iran, Iraq, Isle of Man, Israel, Kazakhstan, Korea, Kuwait, Laos, Lebanon, Lithuania, Luxembourg, Macedonia, Madagascar, Madeira, Mali, Martinique, Mauritania, Mauritius, Monaco, Morocco, Mozambique, Myanmar, Nepal, Netherlands, Niger, Norway, Oman, Pakistan, Paraguay, Peru, Philippines, Poland, Portugal, Romania, Russia, Rwanda, St. Vincent, Senegal, Slovakia, Somalia, Spain, Sudan, Suriname, Sweden, Switzerland, Syria, Thailand, Togo, Tunisia, Turkey, Uruguay, Vietnam, Yugoslavia (now Serbia & Montenegro), Zambia.

UNITED KINGDOM


Bahrain, Bangladesh, Belize, Botswana, Brunei, Cameroon, Channel Islands, China, Cyprus, Dominica, El Salvador, Gambia, Ghana, Gibraltar, Grenade, Guatemala, Guyana, Hong Kong, Iraq, Ireland, Isle of Man, Jordan, Kuwait, Lebanon, Macau, Malawi, Malaysia, Maldives, Malta, Mauritius, Sierra Leone, Singapore, Tanzania, Uganda, United Arab Emirates, United Kingdom, Vietnam, Yemen, Zambia, Zimbabwe.

AUSTRALIA

American Samoa, Argentina, Australia, China, El Salvador, Fiji, Guatemala, Kiribati, Nauru, New Zealand, Okinawa, Panama, Papua New Guinea, St. Vincent, Tajikistan, Tonga, Uruguay.

USA

American Samoa, Anguilla, Antigua, Aruba, Bahamas, Bangladesh, Barbados, Bermuda, Bolivia, Brazil, Cambodia, Canada, Cayman Islands, China (without holes in blades and slightly shorter blades), Colombia, Costa Rica, Cuba, Ecuador, El Salvador, Guam, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Laos, Lebanon, Liberia, Maldives, Micronesia, Montserrat, Netherlands Antilles, Nicaragua, Niger, Okinawa, Panama, Peru, Philippines, Puerto Rico, St. Vincent, Saudi Arabia, Tahiti, Taiwan, Thailand, United States, Venezuela, Vietnam, Virgin Islands (U.S. & British), Yemen.



by **MCKAL**

Patent

US 7220139 B1
CN 1848548A
GB 0614388,7
AU 2006100573
TW M 300917

only use T2.5A (Max. 110V-275W / 240V - 500W) fuse!

FACE BACK

45

45

45

45

45

45

45

315

DESCRIPTION : INSTRUCTION FOR



by **MCKAL**